

「港島綫西延」紀念車票  
 “Extension of Island Line to Western District” Souvenir Ticket Sets

<p>堅尼地城 Kennedy Town</p>	<p>香港大學 HKU</p>	<p>西營盤 Sai Ying Pun</p>
<p>車票 Ticket</p>	<p>車票 Ticket</p>	<p>車票 Ticket</p>
		
<p>記憶體 USB</p>	<p>記憶體 USB</p>	<p>記憶體 USB</p>
		
<p>記憶體尺寸 (約): 83(長)x23(闊) x8(厚)毫米                      USB size (approx.): 83(L)x23(W) x8(D)mm                      記憶體容量(約): 4GB                      USB Capacity (approx.): 4GB                      重量(約): 16 克                      Weight(approx.): 16g                      物料 Material: Non-phthalate PVC</p>	<p>記憶體尺寸 (約): 79(長)x24(闊) x8(厚)毫米                      USB size (approx.): 79(L)x24(W) x8(D)mm                      記憶體容量(約): 4GB                      USB Capacity (approx.): 4GB                      重量(約): 16 克                      Weight(approx.): 16g                      物料 Material: Non-phthalate PVC</p>	<p>記憶體尺寸 (約): 64(長)x23(闊) x8(厚)毫米                      USB size (approx.): 64(L)x23(W) x8(D)mm                      記憶體容量(約): 4GB                      USB Capacity (approx.): 4GB                      重量(約): 12 克                      Weight(approx.): 12g                      物料 Material: Non-phthalate PVC</p>

記憶體系統要求 USB Flash Disk Operation system requirements:

Windows ME / 2000 / XP / 2003 / Vista / 7 / 8, Mac OS 9, Linux Core 2.4 及以上版本 /or above

注意事項:

Caution:

- 1) 內有細小配件, 小心窒息危險  
 Small parts, choking hazard
- 2) 記憶體處於讀/寫狀態時, 請不要拔出  
 Do not unplug the USB Flash Disk while it's in read/write processing mode
- 3) 插入和拔出記憶體的時間差距必須在 5-10 秒鐘或以上  
 Please wait 5-10 seconds or more between plugging in and unplugging the USB Flash Disk
- 4) 由於記憶體格式化, 實際可用的數據儲存量會比被列出儲存量較少  
 Actual capacity for data storage is less than as listed on the USB due to formatting